

FACULTY OF INFORMATION TECHNOLOGY >>> COURSE MATERIAL <<<

INTRODUCTION TO COMPUTER NETWORK Course ID: 502046

Tutorial 7 Configure DHCP on a Wireless Router

Topology



Objectives

- Connect 3 PCs to a wireless router
- Change the DHCP setting to a specific network range
- Configure the clients to obtain their address via DHCP

Background / Scenario

A home user wants to use a wireless router to connect 3 PCs. All 3 PCs should obtain their address automatically from the wireless router.

Instructions

Part 1: Set up the network topology

- Step 1: Add three generic PCs.
- Step 2: Connect each PC to an Ethernet port to the wireless router using straight-through cables.

Part 2: Observe the default DHCP settings

Step 1: After the amber lights have turned green, click **PC0**. Click the **Desktop** tab. Select **IP Configuration**. Select **DHCP** to receive an IP address from **DHCP Enabled Router**.

Step 2: Question:

Record the IP address of the default gateway:

- Step 3: Close the IP Configuration window.
- Step 4: Open a Web Browser.
- Step 5: Enter the IP address of the default gateway recorded earlier into the URL field. When prompted, enter the username **admin** and password **admin**.
- Step 6: Scroll through the Basic Setup page to view default settings, including the default IP address of the wireless router.
- Step 7: Notice that DHCP is enabled, the starting address of the DHCP range and the range of addresses available to clients.

Part 3: Change the default IP address of the wireless router.

- Step 1: Within the Router IP Settings section, change the IP address to: 192.168.5.1.
- Step 2: Scroll to the bottom of the page and click Save Settings.
- Step 3: If it is done correctly, the web page will display an error message. Close the web browser.
- Step 4: Click **IP Configuration** to renew the assigned IP address. Click **Static**. Click **DHCP** to receive new IP address information from the wireless router.
- Step 5: Open the web browser, enter the IP address **192.168.5.1** in the URL field. When prompted, enter the username **admin** and password **admin**.

Part 4: Change the default DHCP range of addresses.

- Step 1: Notice the DHCP Server Start IP Address is updated to the same network as the Router IP
- Step 2: Change the Starting IP Address from 192.168.5.100 to 192.168.5.126.
- Step 3: Change the Maximum Number of Users to 75.
- Step 4: Scroll to the bottom of the page and click **Save Settings**. Close the web browser.
- Step 5: Click **IP Configuration** to renew the assigned IP address. Click **Static**. Click **DHCP** to receive new IP address information from the wireless router.
- Step 6: Select Command Prompt. Enter ipconfig.

Step 7: Question:

Record the IP address for PC0:

Part 5: Enable DHCP on the other PCs.

- Step 1: Click PC1.
- Step 2: Select **Desktop** tab.
- Step 3: Select IP Configuration.
- Step 4: Click DHCP.

Step 5: Question:

Record the IP address for PC1:

- Step 6: Close the configuration window.
- Step 7: Enable DHCP on PC2 following the steps for PC1.

Part 6: Verify connectivity

- Step 1: Click PC2 and select the Desktop tab.
- Step 2: Select Command Prompt.
- Step 3: Enter **ipconfig** at the prompt to view the IP configuration.
- Step 4: At the prompt, enter ping 192.168.5.1 to ping the wireless router.
- Step 5: Enter ping 192.168.5.126 to ping PC0 at the prompt.
- Step 6: At the prompt, enter ping 192.168.5.127 to ping PC1.
- Step 7: The pings to all devices should be successful.

Answer Key

Part 1: Set up the network topology

Part 2: Observe the default DHCP settings

Record the IP address of the default gateway:

192.168.0.1

Part 3: Change the default IP address of the wireless router.

Part 4: Change the default DHCP range of addresses.

Record the IP address for PC0:

192.168.5.126

Part 5: Enable DHCP on the other PCs.

Record the IP address for PC1:

192.168.5.127

Part 6: Verify connectivity